

## Step by step guide to the basics of taking dermatological pictures with the Nikon Coolpix 4300

### Mode

Indicator in the monitor: **P**

Mode dial up M → MENU button → Multi selector Menu → EXP. → Exposure Mode → P

### Image Quality

Indicator in the monitor: **FINE**

MENU button → Menu 2 → QUAL → Image Quality → FINE

### Image Size

Indicator in the monitor: **1024**


MENU button → Menu 2 → QUAL → Image Size → 1600


### Image Sharpening

Indicator in the monitor: **◆**

MENU button → Menu 1 → **◆** → High

### White Balance

Indicator in the monitor: 

Menu button → Menu 1 →  → White Bal Preset → Measure

### Focus mode

Indicator in the monitor: **Flower icon**

Button Focus mode → Flower icon

### Flash mode

Indicator in the monitor: 

Button Flash mode → Flash Cancel

